INSTALLATION GUIDE

Everything you wanted to know but were too afraid to ask

bravado

make some noise




ence

MAKING LIGHT WORK


+61 3 9486 3699 sales@ambiencelighting.com.au **ambiencelighting.com.au** 0

Make a hole 260mm x 125mm in the false ceiling.



2

Position and plug LED driver in ceiling space, like this.



3

Push the housing into the hole by compressing the spring clips, just like that.



Release the spring clips once the fitting fits into the hole and adjust to the required angle, and that's that.

